



Tin Roof Mast Installation Guide

1. Unpack components.



2. Determine the location of mast.



3. Remove relevant roof screws.



4. Re-screw and attach mast baseplate.



5. Ensure baseplate is securely attached (both screws).



6. Remove/undo bolt.



7. Attach mast to baseplate with bolt.



8. Tighten bolt with fingers.



9. Additional tightening with shifter.



10. Position mast vertically.



11. Determine position of first strut.



12. Remove relevant screw.



13. Re-screw/attach strut to roof



14. Screw strut to mast.



15. Attach/screw second strut to roof.



16. If required, adjust strut tab to suit.



17. Attach second strut to mast.



18. Mast Installation complete.

Refer to additional guides for antenna & equipment installation.

